

 **West Marine**<sup>®</sup>  
We make boating more fun!<sup>™</sup>

*Jetty Express*<sup>™</sup>   
**ASSEMBLY INSTRUCTIONS**



Thank you for choosing our product to help improve your boating experience. Your new Jetty Express folding bike will give you years of trouble-free performance.

If you have any questions, call:  
**1-800-270-4262**

**PLEASE READ THESE INSTRUCTIONS  
CAREFULLY BEFORE USING YOUR NEW BIKE.**

**Cut out the registration card and mail immediately!**

From:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Place  
Stamp  
Here

*Jetty Express*<sup>™</sup> 

Warranty Registration  
21624 Marilla Street  
Chatsworth, CA 91311-4123

If you have any questions or problems with your new Jetty Express, please do NOT contact West Marine. Please call our friendly technical staff for assistance.  
**1-800-270-4262**

# SAFETY 1ST

For your safety and enjoyment it is important for you to practice the folding and unfolding of your bicycle several times before riding it for the first time. After carefully following these simple instructions you should be able to successfully fold, or unfold your new bike in a matter of seconds. Always follow the sequence provided in this instruction guide.

- Before you ride your new bike, we recommend that you have it checked out by a professional bike technician. This will insure your safety and insure maximum performance.
- Before each bike ride we suggest that you examine your bike, adjust and tighten all fittings and quick connect locks, and check your brakes and tire pressure.
- If your bike has been damaged or any of the quick lock features are not working properly, **do not ride your bike.** Have it serviced by a qualified technician.
- Before you ride your bike you should know all of the safety regulations in your area. Please observe all safety regulations and rules of the road.
- Additional safety information is available in your "Bicycle Owners Manual" which is supplied separately with this bicycle. Please read it thoroughly before operating this bike.
- Maximum rider weight should not exceed 240 lbs.

# WARRANTY



**WARRANTY REGISTRATION CARD**  
**MAIL IMMEDIATELY; FAILURE TO REGISTER PROMPTLY MAY VOID YOUR WARRANTY.**

PLEASE PRINT CLEARLY

Last Name	First Name	Suite / Apartment
Address	State	Zip Code
City	E-Mail (Optional)	Date Purchased
Phone Number		
Model Purchased	<b>JETTY EXPRESS</b>	
		<b>20</b>

How did you purchase this bicycle?

West Marine Store  West Marine Catalog  West Marine Web Site

If Purchased From A Store, Which Store (City)

State

## LIMITED WARRANTY

This bike includes the following warranty, which is in lieu of all other warranties expressed or implied. This warranty gives you specific rights, and you may have other rights which vary from state to state.

**FRAME, FORK & COMPONENTS** are warranted against faulty materials and workmanship for a period of one year from date of purchase by the initial consumer purchaser, subject to the conditions set forth below. A copy of the dated sales receipt will be required for all warranty claims.

### LIMITATIONS & EXCLUSIONS

This warranty does not cover normal wear and tear or any damage, failure or loss caused by:

1. Accident, neglect, abuse, misuse or loss of supplied parts
2. Competitive cycling in any form or cycling events
3. Stunt riding, ramp jumping, acrobatics or similar activities
4. Use with a motor as a power driven source
5. Improper assembly, maintenance or alterations of any kind
6. Failure to follow instructions in the owner's manual and/or assembly instructions
7. Rust or corrosion due to exposure to the elements

To qualify under the terms of this warranty the defective part must be presented to the store in which the bike was purchased, or to the manufacturer's warranty center, along with the dated sales receipt. If the claim qualifies under the terms of this warranty, the maker will, at its option repair or replace the defective part, without charge, except for labor and shipping costs, if any, to the original purchaser. Repair or replacement of the defective part constitutes the sole and only remedy under this warranty.



# ADJUSTMENTS

You can easily and quickly adjust the height of the seat and handle bars to fit any rider!

Locate the Quick Release Seat Lever or Quick Release Handle Bar Lever. Lift the lever and flip over. Adjust the seat or handle bars as desired. Flip the lever back over to tighten. Make sure lever is always completely tightened before riding. Caution: If the Seat Assembly or Handle Bar Assembly can still turn from side to side, or slide up and down, you will need to tighten the adjusting nut on the other side of the Quick Release Seat Lever before securing.

Note: Seat Assembly can be removed from the bike while the bike is folded, to save additional space! Simply follow the above directions and slide the Seat Post completely out of the frame.




**PLEASE READ YOUR  
"BICYCLE OWNER'S MANUAL"  
BEFORE OPERATING THIS BICYCLE.**

If you have any questions or problems with your new Jetty Express, please do NOT contact West Marine. Please call our friendly technical staff for assistance.

**1-800-270-4262**

# KNOWING YOUR BIKE

Some Helpful Terms...



- A Seat Assembly (includes: seat, seat post)
- B Quick Release Seat Lever
- C Frame Lock
- D Handle Bar Assembly (includes: handle bar, handle bar stem, grips, shifter, brake levers)
- E Quick Release Handle Bar Lever
- F Handle Bar Lock
- G Folding Pedals

# FOLDING

## As Easy As 1-2-3

### 1- Unlock and fold the pedals

Simply push the pedal in slightly towards the bike frame and lift up on the end of the pedal.



### 2- Unlock and fold the handle bars

Loosen the Handle Bar Lock handle by turning it counter-clockwise. Swing the Handle Bar Assembly down to the side of the frame.



### 3- Unlock and fold the frame

Standing on the bike chain side of the bike, pull up on the Frame Lock quick connect lever to release it. Rotate the quick connect lever, spring loaded bolt and locking pin assembly away from the frame.



Slightly lift up on the quick connect lever, spring loaded bolt and locking pin assembly to allow the locking pin to disengage and the two halves of the frame to separate. Swing the front and rear halves of the bike together.



### Optional- Lower the Seat Assembly

To save additional space, you can lower the Seat Assembly all the way down to the frame. Pull up the Quick Release Seat Lever and flip over. Allow the Seat Assembly to slide all the way down to the frame.



See "Adjustments" on page 6 for additional tips.

# UNFOLDING

## As Easy As 3-2-1

### 3- Unfold and lock the frame

Standing on the bike chain side of the bike, swing the front and rear halves of the bike into position. Slightly lift up on the quick connect lever, spring loaded bolt and locking pin assembly to allow the two halves of the frame to align. Release the assembly, allowing the locking pin to drop into position. Rotate the assembly into position and fold down the quick connect lever. Be sure that the spring loaded bolt is tight and the fold down lever rests flush against the surface. It should lock firmly in place.



### 2- Unfold and lock the handle bars

Swing the Handle Bar Assembly up into position. Align the wedge shaped block into position and tighten down the Handle Bar Lock handle by turning it clockwise, until secure.



### 1- Unfold and lock the pedals

Simply pull up on your pedal until it snaps into place.



See "Adjustments" on page 6 for additional tips.